



Product Data Sheet

Part # 17101

Automatic transmission Cleaner

Soltec™ Automatic Transmission Cleaner is an effective blend of solvent cleaners and dispersants that quickly remove and suspend accumulated deposits from the valve body, filter-screen and other system components. This product is infused into the transmission through the dip-stick tube prior to activating **Soltec™ Automatic Transmission Fluid Exchanger**. This product is used in conjunction with **Soltec™ Automatic Transmission Treatment**.

- Helps suspend varnish, sludge and contaminants from the transmission system and housing, allowing for easier, more complete evacuation of contaminants during the fluid exchange process.
- Compatible with rubber seals and other system components.
- Prepares the torque converter, pump, ATF cooler and fluid lines for new ATF



Application:

1.) Pour entire contents of **Automatic Transmission Fluid Cleaner** into the transmission through the dipstick tube before beginning a fluid-exchange process. **2.)** With the engine running and parking brake set, place one foot on the brake pedal and slowly shift the transmission through all gears (continue this process for 5-8 minutes). **3.)** Put transmission into park, and shut off the engine. **4.)** Following the directions provided with the **Soltec™ Automatic Transmission Fluid Exchanger** to complete the process.

Specifications:

<u>Test</u>	<u>ASTM Method</u>	<u>Typical Results</u>
Appearance	-	Clear & Bright
Color	-	Light Straw
Odor	-	Petroleum
Specific Gravity @ 60°F (g/ml)	D1298	0.87
Density, U.S. (lbs/gal) @ 60°F	D1250	7.27
Viscosity, cSt @ 100°C	D445	~4
Boiling Point (°F)	-	>415
Flash Point (°F) PMCC	D93	280

Packaging: Fill: 10 Oz Case Quantity: Part of 17502 2-pack kit 12/case Case Weight: 20 lbs