



# DIFFERENTIAL FLUID EXCHANGER

The Differential Fluid Exchanger comes with a wide range of flexible tube adapters to fit any fill opening. Once the appropriate adapter is attached to the service hose and is inserted into the differential, the process is simple. The removal and addition of fluid is then conveniently controlled on the service hose with two flow valves. The Differential Fluid Exchanger has the flexibility to perform a complete exchange in less than 10 minutes, even in colder environments.

**Part # 95670**



## FEATURES / BENEFITS

- HANGING CHAIN FOR EASY POSITIONING
- LARGE-CAPACITY 5-GALLON WASTE TANK
- AIR OPERATED; EASY TWO-SWITCH OPERATION
- SEPARATE 3.5 GALLON NEW FLUID TANK IN THE REAR
- CAPABLE OF REMOVING UP TO 90-WEIGHT GEAR OIL
- FLOW-CONTROL VALVES ARE CONVENIENTLY LOCATED ON SERVICE HOSE
- FULL SET OF FLEXIBLE ADAPTORS T
- CAN ALSO BE USED TO REMOVE MANUAL AND AUTOMATIC ATF FLUID

## EQUIPMENT SPECIFICATIONS:

Dimensions:	24" H x 18.5" W x 38.5" D
Weight :	80 lbs. (36.28 kg)
Chassis:	Low-density polyethylene
Power:	Compressed air
Capacity:	new 3.5 gal. / used 5 gal.
Hoses:	10' CLEAR SUPPLY HOSE